

IMPORTANT SAFETY INSTRUCTIONS

1. **READ INSTRUCTIONS** — All the safety and operating instructions should be read before the appliance is operated.
2. **RETAIN INSTRUCTIONS** — The safety and operating instructions should be retained for future reference.
3. **HEED WARNING** — All warnings on the appliance and in the operating instructions should be adhered to.
4. **FOLLOW INSTRUCTIONS** — All operating and use instructions should be followed.
5. **WATER AND MOISTURE** — The appliance should not be used near water, near a bathtub, wash-bowl, kitchen sink, laundry tub, swimming pool, or in a wet basement, for example.
6. **VENTILATION** — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings. This product should never be placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
7. **HEAT** — The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
8. **POWER SOURCES** — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
9. **GROUNDING OR POLARIZATION** — Precautions should be taken to insure that the grounding or polarization means of an appliance are not defeated.
10. **POWER-CORD PROTECTION** — Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point at which they exit from the appliance.
11. **CLEANING** — The appliance should be cleaned only as recommended by the manufacturer.
12. **NONUSE PERIODS** — The power cord of the appliance should be unplugged from the outlet when the appliance is to be left unused for a long period of time.
13. **OBJECT AND LIQUID ENTRY** — Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
14. **CARTS AND STANDS** — If the appliance is used with a cart or stand, the cart or stand should be a type recommended by the manufacturer.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
15. **MOUNTING** — The appliance should be mounted only as recommended by the manufacturer.
16. **DAMAGE REQUIRING SERVICE** — The appliance should be serviced by qualified service personnel when:
 - A. The power-supply cord or plug has been damaged;
 - B. Objects have fallen onto, or liquid has been spilled into the appliance enclosure;
 - C. The appliance has been exposed to rain;
 - D. The appliance has been dropped; or the enclosure damaged
 - E. The appliance does not appear to operate normally or exhibits a marked change in performance.
17. **SERVICING** — The user should not attempt to service the appliance beyond that described in the user's operating instructions. All other servicing should be referred to qualified service personnel.
18. **OVERLOADING** — Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.